

## Operating instructions **hotplate 1-System**

### INTRODUCTION

"hotplate1 system" consists of two components:

1. **hotplate** with a special coating on the underside
2. **hottable** - table inductively heats the plates and is powered by low voltage powered by 12V.

### PREPARATION

connect the **hottable** to the 230V power supply. The LED light in the edge of the table then lights up for 3 seconds.

### OPERATION

- Switch on with the push button (under the tabletop), to the left of the red foot. Heating goes on standby, and the LED light is in continuous operation.
- Place the specially coated **hotplate** on the **hottable**
- The plate must be in the center of the LED light and about 1 cm inside the edge of the table
- If the platter moves out of position, the LED light will flash until the platter is back in the correct position



The induction heat is automatically activated when the **hotplate** is set up and provides it with high heat for around 30 minutes. The heating element then switches itself off. If table seats remain without plates, they remain in standby mode and switch off automatically after 30 minutes.

To start the **hottable** again: activate the table again with the push button, the heating function starts automatically for another 30 minutes.

## WARNINGS

- The **hotplate1** system is state-of-the-art and in accordance with the applicable CE directives. Safe operation is guaranteed.
- The table works with electromagnetic waves that are induced with 12 V 30 watts therefore not to be compared with induction hobs.
- During operation, the underside of the **hotplate** is kept at high heat.
- Placement of serving tray on the **hottable**, invariably made of wood or Plastic. None metal or silver plated.  
All users must be made aware of this risk in order to avoid any discomfort caused by touching the very hot plates.  
In the event of damage caused by negligent operation, the warranty Claim.

If you have any questions or would like to place an order, please contact us:

**hotplate1** UG (haftungsbeschränkt)

Jochen Stephan [hotplate@hotplate1.com](mailto:hotplate@hotplate1.com)

Tel: +49 171 3080322